Mechanical Repair Coverage

Essential protection against costly repairs.



Drive with confidence, knowing we've got your back.

A breakdown can be troubling enough without the added worry of expensive repairs. That's why we're pleased to bring you Mechanical Repair Coverage:

Mechanical Repair Coverage

May help limit unexpected covered repair costs as your vehicle ages, potentially saving you thousands of dollars in repairs. What's more, it works at any authorized repair facility in the U.S. or Canada.

As your vehicle gets older, the risk and cost of repairs increases.



And the average cost of those repairs can be expensive.*



See the reverse side for information about plan tiers and which one is right for you.

*Actual costs may vary by vehicle year, make and model. Prices are based on actual claim experience of Consumer Program Administrators, Inc. and its affiliated companies' customers as of January 2021. Your experience may be different.

Coverage Benefits

- Rental reimbursement: up to \$35 per day (5-day maximum, 10-day maximum for parts delay); available on the first day of a covered repair
- 24-hour emergency roadside assistance: up to \$100 per occurrence; includes towing, battery jumpstart, fluid delivery, flat tire assistance and lock-out service
- Travel expense reimbursement: up to \$200 per day (5-day maximum) for lodging, food and transportation expenses when a covered breakdown occurs 100 miles or more from home and your vehicle is held overnight at a repair facility; not available to residents of NY
- Key replacement: up to \$800 per occurrence for the repair or, if nonrepairable, the replacement of lost, stolen or damaged keys (including fob and/or remote) including any programming; not available to residents of CA, CT, GA, ME, MA, MT, ND, PA, SD, VT, WI and WY
- Paintless dent repair: provides for the repair of dings and dents, no larger than 4 inches in length/diameter, that are within an accessible area on a body panel of your vehicle and that are repairable through existing paintless dent repair techniques; not available to residents of CA and CT
- Commercial use: pays for covered breakdowns when your vehicle is used for permitted commercial purposes; not available to residents of CA
- Rideshare: pays for covered breakdowns when your vehicle is used for ride-sharing purposes such as Uber or Lyft; not available to residents of CA
- Lift kit/leveling kit: pays for covered breakdowns when your vehicle is equipped with a lift kit not to exceed 6 inches or leveling kit not to exceed 2.5 inches (lift kit or leveling kit components themselves are not covered); not available to residents of CA
- Mobility equipment: provides coverage for mobility equipment components when installed by the manufacturer or a licensed, manufacturer-authorized installer; not available to residents of CA
- Good at any authorized repair facility in the continental United States of America, Alaska, Hawaii and Canada
- No out of pocket expense (except for any deductible): the administrator pays the repair facility directly for the covered repair
- **Transferable:** if you sell your vehicle privately, the coverage can be transferred (for an administrative fee), adding resale value and appeal
- Cancelable: receive a full refund for an unused agreement within the first 60 days, or a prorated refund thereafter less an administrative fee*
- * Cancellation provision and administrative fees vary by state.

PLATINUM PLAN

We will remedy any covered breakdown of your vehicle except items listed under the section titled "Maintenance & Parts This Service Contract/Policy Does Not Cover" and "Service Contract/Policy Limitations."

ADDITIONAL PARTS[†] COVERED BY PLATINUM:

HIGH TECH

Automatic leveling system, cruise control actuator and module, electronic instrument panel control module, electronic stability control system, electronic traction control system, GPS/navigation system and antenna assembly, heated seat element and cooling seat components, rollover protection system. All gauges, sensors and relays.

ENTERTAINMENT SYSTEM

Antenna assembly, compact disc player/changer, DVD player and monitor, graphic equalizer, radio and speakers, satellite radio, telephone prewire/ Bluetooth connectivity.

CONVENIENCE

Auxiliary power point, buzzer/chime (headlamps on, key in ignition). cigarette lighter, clock, compass, electrical or mechanical gas cover and trunk releases, glove box lamp (excluding bulb), headlight wiper motor transmission, illuminated entry lamp (excluding bulb), illuminated vanity mirrors, memory seat system, trip/mileage computer, trunk lamp (excluding bulb), volt/amp gauge, wiper motor transmission.

SAFETY AND SECURITY

Heads up display, night vision system, OnStar® system, remote keyless entry transmitter and receiver module, tailgate and hatchback actuators, theft alarm system, tire pressure monitoring system.

MISCELLANEOUS

Blend door motors, blower motor resistor (regulates fan speed), door hinges, mechanical seat adjustment, outside mirror remote adjustors. rear hatch or hood struts, rear suspension and steering components.

AND MORE!

SILVER PLAN SILVER PLAN COVERS COMPONENTS LISTED BELOW.*

† Factory Installed.

1. ENGINE

GASOLINE ENGINE		
Cylinder block and all internal lubricated parts Crankshaft Rod and main bearings Cam bearings expansion (freeze) plugs Connecting rods Wrist pins Piston Piston Piston Piston Sitons Cam bear Cam tower Lifters Cylinder head Valves and guides Valves prings	Rocker arms (cam followers) Pushrods Timing chain housing (cover) Timing chain and sprockets Timing belt and pulleys Timing belt and pulleys Timing belt ensioner Intake and exhaust manifolds Flywheel Balance shafts Harmonic balancer and retainer bolt Crankshaft pulley Valve covers Oll pan	Oil pump and pressure relief valve Engine oil cooler hoses Oil filter adapter/ housing Engine oil sending unit Engine oil sending unit Mater pump Temperature sending unit Thermostat and housing Fuel supply pump Vacuum pump Dipstick and tube Fasteners for all listed components

TURBOCHARGED/SUPERCHARGED/ROTARY/DIESEL/ ENHANCED ENGINES

 All of the above listed parts or equivalent 	 Waste gate controller Intercooler 	 Clutch and pulley Bypass valve
plus:	Hard lines	 Injection pump
 Turbocharger 	 Compressor 	 Lines and nozzles

2. TRANSMISSION

AUTOMATIC			
Case and all internal lubricated parts Oil pump Valve body Torque converter Vacuum modulator	Governor Main shaft Clutches Bands Drums Gear sets Bearings Bushings	Sealing rings TV cable Solenoids Electronic shift control unit Transmission mounts Cooler	 Cooler hoses and hard lines Dipstick and tube Fasteners for all listed components

STANDARD

 Main shaft Synchronizers
 Fasteners for Case and Bearings Gear sets all listed all internal Bushings Shift forks components lubricated parts

TRANSFER GASE - (4A4 VEHICLES)			LEO/
	 Case and all 	 Chain and 	 Mounts
	internal lubricated	sprockets	 Electronic
	parts	 Bearings 	and vacuum
	 Main shaft 	 Bushings 	engagement
	 Gear sets 		components

TRANSFER GASE (AVANEURO) FO

3. FRONT WHEEL DRIVE

 Final drive housing and all internal parts Carrier case Gear sets Chain and sprockets 	Bearings Bushings Axle shafts Universal joints Front hub bearings	Rear hub bearings Locking hub assemblies (4X4) Drive shaft support Fasteners for all listed components
4. REAR WHEEL D	RIVE	
Drive axle housing and a	II • Bushings	Propeller shafts

 Limited slip clutch pack 	
	 Drive shaft support
 Front hub bearings 	 Fasteners for all listed
 Rear hub bearings 	components
	• Axle shafts • Front hub bearings

5. STEERING (DOES NOT INCLUDE "REAR WHEEL STEERING" COMPONENTS)

Housing/case and all internal lubricated parts Rack-and-pinion- equipped valve assembly Sector shaft Rack mounts and cushions Inner rod ends and bellows boots	Speed sensor- or steering gear- equipped pitman shaft and valve assembly Sealing rings Bearings Bushings Pitman arm Center link Tie rods	Idler arm Power steering pump and pulley Electric power steering motor Fluid reservoir Pressure and return hoses Cooler and hard lines	Power cylinde assembly Steering main and intermediate shafts Coupling Fasteners for all listed components

6. FRONT SUSPENSION

 Upper and lower control arms Bump stop cushions Control arm shafts Torsion bar mounts and bushings 	Upper and lower ball joints including dust boots Steering knuckle (spindle)	Wheel bearings and seals Stabilizer shaft Stabilizer linkage including mounts and bushings	Strut rods and bushings King pins Fasteners for all listed components

Master cylinder	Disc brake	Backing plates	
 Assist booster 	calipers and rear	 Springs 	linkage and
 Wheel cylinders 	caliper actuators	 Clips and 	cables
 Combination 	 Hard lines and 	retainers	 Fasteners for all
valve	fittings	 Self-adjusters 	listed components

8. ELECTRICAL

Alternator Voltage regulator Front and rear windshield wiper motors and delay controller Starter motor and drive Starter solenoid Wiring harnesses Manually operated switches (specifically turn signal, headlight, dimmer and wiper switches)	Mechanically actuated switches (ignition, brake light and neutral safety switch) Electronic fuel injection system including all input/sensor & output/ control units (except EGR valve) related to the fuel injection system Electronic ignition module Distributor and coil Engine management control unit
	 Knock sensor and oxygen sensor

mounting brackets cutoff switches Clutch and pulley High/low pressure Condenser hoses Evaporator Pressure cycling switch Orifice tube Thermostat Accumulator Drier Temperature control programmer head	 Freon refrigerant if necessary in conjunction with the repairs of all listed components
--	---

10. BASIC HYBRID/ELECTRIC VEHICLE COMPONENTS

 Electric motor/generator(s) and all internal components 	 Power split device and all internal components
 Inverter/Converter/transformer units and all internal components Inverter/converter/transformer units cover Continuously variable transmission (CVT) and all internal components 	 Reduction/reducer box and all internal components and fasteners for all listed components Hybrid battery junction block Hybrid battery main battery cable Electric alternating current
	compressor

11. SEALS AND GASKETS

All seals and gaskets on the assemblies listed above

GOLD PLAN ALL SILVER PLAN COMPONENTS PLUS:"

12. ADVANCED COMPONENTS

Anti-lock brake system Power seat motor(s) and transmission(s) Power window motor(s) and power regulator(s) Power door lock actuator(s) Digital and analog instrument display(s) Low fuel sensor	Windshield wiper washer pump(s) Heater/AC blower motor Heater core assembly Heater control valve	Temperature sensor and relay Fuel tank and hard lines Fuel tank sending unit Power sun roof motor Convertible top motor Constant velocity joints
Low fuel sensor Low coolant sensor Low oil sensor	Heater control valve Radiator	Constant velocity joints Horn assembly

13. ADVANCED HYBRID/ELECTRIC VEHICLE COMPONENTS

Onboard battery charging system	 Three-phase high- voltage cables 	Sensors ECU & ECM (electronic
Battery charge controller Motor/generator belt	Hydraulic or electric regenerative braking	control units/electronic control modules)
tensioner	system	 Power switch/button
 Drive motor dampener 	Onboard computer	 Controller/electronic
Voltage inverter reservoir	system including all relays	throttle control system

MEMBER'S CHOICE® Mechanical Repair Coverage (MRC) pays for the cost of covered repairs less any deductible

Deductible**: \$0 \$100 \$250 \$500

What's Not Covered

NORMAL MAINTENANCE SERVICES AND PARTS

 Maintenance services and parts described in the manufacturer's maintenance schedule for your vehicle

Other normal maintenance services and parts including:

- Engine tune-up, includes spark plugs, glow plugs, ignition wires, distributor cap and rotor - All batteries, including but not limited to hybrid/electric vehicle batteries
- Filters, lubricants or fluids, air conditioning refrigerant, engine coolant

- All hoses and belts (not specifically listed), wiper blades, brake pads and shoes, brake rotors and drums, suspension alignment

BODY STRUCTURE AND PARTS

Glass, glass framework and fastening adhesives, trim, moldings, bright metal, paint, sheet metal, bumpers, alignment of body parts, flexible body parts, door panels, body panels, structural framework, convertible top framework,

structural welds, hinges, door handles, vinyl and convertible tops and nonmechanical removable hardtop assemblies

OTHER PARTS

Constant velocity boots, tires, wheel covers, wheel rims, wheels, wheel balancing, shock absorbers, suspension air bags, exhaust system, catalytic converter, friction clutch disc and pressure plate and clutch release bearing. sealed beam head lamps, light bulbs, lenses, upholstery

- ABUSE, MISUSE, AND LACK OF PROPER MAINTENANCE AFTERMARKET EOUIPMENT, COMPONENTS, SYSTEMS OR
- ACCESSORIES NOT INSTALLED BY THE MANUFACTURER

• NORMAL WEAR AND TEAR where no failure has occurred PRE-EXISTING CONDITIONS*** AND CORROSION

Certain conditions and components are excluded, such as inadequate maintenance and loss of coolant or lubrication of the vehicle. See the exclusions section of the service contract for complete details.

*Components not listed are not covered. **Not every deductible available on all MRC Plans or Terms. ***N/A in A7 and GA

There's so much our Mechanical Repair Coverage can do for you. Talk to us about the plan that's right for you today.

Mechanical Repair Coverage is provided and administered by Consumer Program Administrators, Inc. in all states except CA, where coverage is offered as insurance by Virginia Surety Company, Inc., in NH, where coverage is provided and administered by Consumer Program Administrators, Inc. dba Consumer Warranty Program Administrators, in TX, where coverage is provided and administered by Consumer Program Administrators, Inc. dba The Administrators of Consumer Programs (TX License #175), in FL and OK, where coverage is provided and administered by Automotive Warranty Services of Florida, Inc. (Florida License #60023 and Oklahoma License #44198051), and in WA, where coverage is provided by National Product Care Company and administered by Consumer Program Administrators, Inc., all located at 175 West Jackson Blvd., Chicago, Illinois 60604, 1-800-752-6265. This coverage is made available to you by CUNA Mutual Insurance Agency, Inc. Coverage varies by state. Replacement parts may be new, used, non-OEM or remanufactured. Be sure to read the Vehicle Service Contract or the Insurance Policy, which will explain the exact terms, conditions, and exclusions of this voluntary product.

	7. BRAKES	
 Fasteners for all listed components 	Master cylinder Assist booster Wheel cylinders Combination	• Disc cali cali

laster cylinder ssist booster /heel cylinders combination alve	 DISC brake calipers and rear caliper actuators Hard lines and fittings 	 Backing plates Springs Clips and retainers Self-adjusters 	 Parking brake linkage and cables Fasteners for a listed component

9. AIR CONDITIONING

Compressor and mounting brackets Clutch and pulley Condenser	 High/low pressure cutoff switches High/low pressure hoses 	 Fasteners for all listed components Freon refrigerant if necessary in conjun
Evaporator Orifice tube Accumulator Temperature control	 Pressure cycling switch Thermostat Drier Temperature control 	with the repairs of all listed components